25 Year Residential Water Resistant Laminate Warranty

The manufacture warrants to the original purchaser that the flooring will be free of manufacturing defects, and the surface will not wear through*, stain or fade from sunlight or artificial light when used under normal residential traffic conditions. *Wear-through is defined as total loss of pattern in a minimum of 2 square inch area. Scratches and loss of gloss are not considered as wear-through. If the product wears through, stains or fades, we will at its option replace or refund the portion of the floor in question as covered under this warranty. This warranty does not cover labor, nor any other incidental expenses incurred as a result of covered defect. Should the original floor be discontinued. we will replace the defective material with a floor of equal value. This warranty is exclusive to the original purchaser and in lieu of all other warranties, expressed or implied, and all other remedies, guarantees or liabilities arising by law or otherwise

10 Year Commercial Water Resistant Laminate Warranty

The manufacturer warrants to the original purchaser that the flooring will be free of manufacturing defects, and the surface will not wear through*, stain or fade from sunlight or artificial light for 10 years after the date of purchase of the product when used under normal commercial traffic conditions. *Wear-through is defined as total loss of pattern in a minimum of 2 square inch area. Scratches and loss of gloss are not considered as wear-through. Heavier traffic areas such as entry foyers, food preparation areas such as commercial kitchens, and any areas with heavy rolling loads are not recommended. If the product wears through, stains or fades, we will at its option replace or refund the portion of the floor in question as covered under this warranty. This warranty does not cover labor nor any other incidental expenses incurred as a result of covered defect. Should the original floor be discontinued, we will replace the defective material with a floor of equal value. This warranty is exclusive to the original purchaser and in lieu of all other warranties, expressed or implied, and all other remedies, guarantees or liabilities arising by law or otherwise

72 Hour Standin gWater Laminate Warrant y

The manufacturer will resist damage from moisture due to wet mopping and everyday household spills removed within 72 hours. This product is water resistant. However, when excessive moisture accumulates in buildings or on building materials, mold and/or mildew growth can occur (particularly if the moisture problem remains undiscovered and unaddressed). The moisture warranty excludes damage resulting from mold and/or mildew growth due to prolonged exposure to moisture. This warranty does not cover flooding.

Terms and Conditions for Water Resistant Laminate Warranty

- The Laminate Flooring panels must be properly installed in accordance with laminate flooring installation instructions, and must be used for indoor use only.
- This warranty does not cover negligence, improper installation/maintenance, insufficient protection, improper alterations to the original materials, insects, severe accidents, exposure to extreme heat, bums, fire, natural disasters.
- The floor must be properly maintained to consider a claim. Improper maintenance can damage your floor. Sweep the floor on a regular basis, at least once per week. If you use a vacuum cleaner the beater bar must be tumed off. The beater bar will damage your floor. No Wet Mopping. We recommend using Bona laminate floor cleaner by spraying it on the mop head not directly on the floor. Never use a wax based product on your floor
- Floors installed in bathrooms or saunas are not covered under warranty.
- This warranty does not cover transition accessories or moldings
- This warranty only applies to 1st quality product purchases made after the edition date of these warranty conditions for the designated time period when the product is installed in a private residence.
- Laminate flooring panels must be inspected prior to installation under sufficient lighting
- Products with visible defects must never be installed under any circumstance. Laminate flooring panels installed with any manufacturing defect are not covered by this warranty. Any defect must be reported prior to installation and within 30 days of purchase in order to be covered. Color or gloss issues as a result of adding material at a later date from non-warranty repairs are excluded
- This Warranty is non-transferable and only applies to the original end consumer
- This product warranty only applies to defects inherent to the material supplied. This means any material or production defects, acknowledged by the manufacturer. It includes the delaminating or reduced resistance of the wear layer. The manufacturer will repair or replace the product, at its option. When replacement of the flooring is made, only new panels from the current product range at the time the complaint is upheld will be supplied by the distributor or retailer. There will be no other form of compensation.
- This warranty does not apply to laminate flooring that has been put to abnormal use or conditions or abused in any way. Abnormal use or conditions includes, but is not limited to, water damage from plumbing, storm or flood, damage from smoke, fire or other casualty events; damage caused by negligence, improper alterations of the original manufactured product. Abuse is any use of the flooring that is unreasonable considering the normal and expected uses of a laminate floor in a residential environment. The damage to the product must be evident, measuring the size of a dime and must not be the result of abusive, abnormal conditions or accidents, such as but not limited to, damage of mechanical nature, severe impact or scratches (caused by dragging objects or furniture) or cutting. The feet of furniture with castors must be fitted with soft rubber wheels, an adequate protective mat or protective castor cups must be put under this furniture. This warranty does not apply to laminate flooring that has been put to abnormal use or conditions
- This warranty does not apply to damage from extreme heat, dryness, moisture of any kind other than regular cleaning as has been explained in this warranty. You must maintain the temperature 65F to 85F and humidity 35% to 55% in your home. Fluctuations in temperature or humidity can damage your floor
- This warranty excludes damages caused by water, included but not limited to a and plumbing failures, natural disaster such as floods, urine, or any standing wa
- This warranty excludes damages caused by water or moisture trapped beneath the floor due to an improper sub floor or underlayment without a moister barrier
- We will not be responsible for any loss of time, inconvenience expenses, costs or consequential nages caused by or resulting directly or indirectly from a problem about which the claim was

Installation Instructions

CENERAL

Method A: Angle-In installation method

Position the plank to be installed at an angle of 20 to 30° to the plank already installed. Move the plank gently up and down and at the same time exert forward pressure. The planks will automatically click into place. You can either insert the tongue into the groove, or the groove into the tongue. The tongue in groove method is the most common and the easiest way.

Method B: Flat installation method

(Flat installation method): You can also tap the planks into each other without lifting. For this method you will need a tapping block. The planks should not be joined with a single tap and the tapping block should be sitting flat on the floor. To avoid damaging the planks you must tap them together gradually. Use this method only in cases where you are unable to use the Angle-In method. The rest of your floor should be installed using the angle-In method.

TOOLS FOR INSTALLING THE FLOOR

For best results, it is essential that you follow the installation instructions exactly. Besides the regular tools for installing laminate floors (i.e. hammer, saw, pencil, measure) you will also need the following accessories:

- Tapping Block
 Maintenance products
- Underlayment system

You may also need to saw the planks. To obtain a clean cut, the pattern side should face down when you use a jigsaw, sabre saw or circular handsaw and up when you use a handsaw, table saw or a crosscut saw.

8 FOCUS POINTS

- Make sure the planks are mixed sufficiently when you install them, so that you do not end up with too many identical, light or dark planks next to each other.
 Check all planks in daylight before and during installation. Defective planks
- must never be used.

 3. The floor should preferably be installed parallel to how the light enters the room. The ideal conditions are 15-20°C (59-68°F) at a relative humidity of 50-
- 4. Let the planks acclimate for 48 hours in the unopened packaging at the normal room temperature in the middle of the room where the floor is to be installed. *Normal conditions means a difference of no more than 25°F and 20% relative humidity between the stocking/transportation environment of the flooring and the final installation environment of the flooring.

 5. Room humidity can vary according to the season, so it is vital that the floor is
- able to expand and contract. For this reason, make sure you leave an expansion joint of minimum 10 to 12 mm (3/8" to 1/2") on all sides of the floor, around pipes thresholds, under doors and around any fixed/stationary objects (floor vents, kitchen islands, etc.,).
- 6. Large rooms must have expansion joints every 13 m (40 feet) width-wise to the planks and every 13 m (40 feet) length-wise. It is recommended to provide a expansion joint between different rooms (e.g. under the door). Expansion joints can be finished by means of a molding that is attached to the subfloor
- can be finished by means of a molding that is attached to the subfloor.

 7. Ensure that the end joints of the planks in two successive rows are never in line. Always ensure that the joints are staggered by at least 15 cm / 6 inches.

 8. A moisture barrier must be used if the subfloor moisture emissions are greater than 3 lbs per 1000 sq/sf or warranty is voided. Both Calcium Chloride testing and Concrete Moisture Testing is required to verify this.

 9. We recommend you purchase a few extra cartons of flooring. This will be useful to you if you have some damaged pieces, miscalculate the size of the room, or miss cut some pieces. This also will help you if your floor needs a repair but your product is no longer manufactured.
- but your product is no longer manufactured.

PRECAUTIONS

- Protect furniture and chair legs with proper felt or rubber caps
- Avoid bringing dirt, water and sand indoors by providing a suitable solid backed floor mat at the door.
 Furniture on casters/wheels must use soft, rubber wheels that are suitable for a
- laminate floor and/or use a suitable protective mat,

MAINTENANCE

- Never use wax, polish, oils, soaps, detergents, shine enhancers, or varnish on the floor
- * For dry maintenance, we recommend a dust mop or vacuum cleaner with soft bristle brush only.
- · For slightly damp maintenance, we recommend a laminate cleaner which you spray directly and lightly on a duster. Always wipe dry immediately until no more moisture is visible on the floor. The use of other cleaning products might damage your floor. For bevel edge products, we strongly recommend dry cleaning only.
- Do not use any type of cleaning machine such as spray mops, steam cleaners/ mops or power cleaners.
- Wet maintenance is absolutely forbidden. Remove any water immediately Our laminates are not suitable for use in damp spaces like saunas
- Remove stubborn stains carefully with acetone based fingernail polish remover. Never use scouring products!
- In case your floor needs repair, the planks can easily be removed in minutes without replacing the entire floor. The required expansion gap must be in place around the room's perimeter and extra flooring should be available for use in the repair. Enjoy your floor.

In any environment, leave a concealed 3/8"minimum expansion space on all sides of the floor, including pipes, thresholds, doorways, and any fixed/stationary objects (door vents, kitchen islands, etc.).

